









VIDEO TUTORIAL

① Important!


This replacement procedure can be used for: MERCEDES-BENZ C-CLASS (W203) C 240 (203.061)

The steps may slightly vary depending on the car design.

WWW.AUTODOC.CO.UK 1–20



REPLACEMENT: BRAKE PADS – MERCEDES W203. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- Nylon cleaning brush
- All-purpose cleaning spray
- Brake cleaner
- Anti-squeal paste
- Copper grease

- Torque wrench
- Wheel impact socket #17
- Hammer
- Pin punch
- Crow bar
- Wheel chock

WWW.AUTODOC.CO.UK 2–20




Replacement: brake pads – Mercedes W203. AUTODOC experts recommend:

- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1



Open the bonnet. Unscrew the brake fluid reservoir cap.

WWW.AUTODOC.CO.UK 3–20



Secure the wheels with chocks.





Loosen the wheel mounting bolts. Use wheel impact socket #17.





Raise the rear of the car and secure on supports.

WWW.AUTODOC.CO.UK 4–20





Unscrew the wheel bolts.

AUTODOC recommends:

 Important! Hold the wheel while unscrewing the fastening bolts. Mercedes W203

6



Remove the wheel.

WWW.AUTODOC.CO.UK 5–20





Clean the brake pads fasteners. Use a wire brush. Use all-purpose cleaning spray.

8



Remove the brake pad retaining pin. Use a pin punch. Use a hammer.

WWW.AUTODOC.CO.UK 6–20





Remove the retaining spring of the brake pads.

10



Spread the brake pads. Use a crowbar.

WWW.AUTODOC.CO.UK 7–20






Remove the brake pads.

Replacement: brake pads – Mercedes W203. Tip:

 Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

12



Treat the brake caliper piston. Use a nylon cleaning brush. Use a brake cleaner.


WWW.AUTODOC.CO.UK 8–20



AUTODOC recommends:

 Replacement: brake pads – Mercedes W203. After applying the spray, wait a few minutes.

13



Press in the brake caliper piston. Use a crowbar (2 pieces).

14



Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use anti-squeal paste.


WWW.AUTODOC.CO.UK 9–20



Replacement: brake pads – Mercedes W203. AUTODOC recommends:

• Make sure the disc surface is clean before installing the pads.

15



Install new brake pads.

AUTODOC recommends:

• Make sure the pads are installed with linings facing the disc.


WWW.AUTODOC.CO.UK 10–20





Install the retaining spring of the brake pads.

17



Install the brake pad retaining pin. Use a pin punch. Use a hammer.

WWW.AUTODOC.CO.UK 11–20





Treat the surface where the brake disc contacts the wheel rim. Use copper grease.

19



Clean the brake disk surface. Use a brake cleaner.

Replacement: brake pads – Mercedes W203. Professionals recommend:

After applying the spray, wait a few minutes.

WWW.AUTODOC.CO.UK 12–20





Install the wheel.

AUTODOC recommends:

 Important! Hold the wheel while screwing in the fastening bolts. Mercedes W203

21



Screw in the wheel bolts. Use wheel impact socket #17.

WWW.AUTODOC.CO.UK 13–20





Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 nm torque.

23



Remove the jacks and chocks.

Replacement: brake pads – Mercedes W203. Tip from AUTODOC:

 Check the brake fluid level in the expansion tank and refill if necessary.

WWW.AUTODOC.CO.UK 14–20





Tighten the brake fluid reservoir cap. Close the hood.

AUTODOC recommends:

- Mercedes W203 Without starting the engine, press the brake pedal several times until it feels firm.
- Slow down smoothly for first 150-200 km after the brake pads replacement. Avoid unneccessary and sharp braking to a stop.

WWW.AUTODOC.CO.UK 15–20



DID YOU FIND THESE INSTRUCTIONS HELPFUL?

YES

NO




BECOME A MEMBER OF AUTODOC CLUB!

WWW.AUTODOC.CO.UK 16–20



AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE





WWW.AUTODOC.CO.UK 17–20







WWW.AUTODOC.CO.UK 18–20







WWW.AUTODOC.CO.UK 19–20





(i) Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shal not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.

WWW.AUTODOC.CO.UK 20–20